




Scan for  
Video

## ANGLE ON LONG SIDE AND TOP TAP ON SHORT SIDE WITH TAPPING BLOCK



Figures 1 & 2 - Place plank "A" against the wall. Continue by engaging plank "B" and "C" onto plank "A". When engaging plank "C" please assure the end joint of plank "C" is aligned to the end joint of plank "B". Please see Figures 1 and 2 for guidance.

Figure 3 - Fold plank "C". **\*Important:** Before folding plank "C" please ensure the planks are aligned in the right position to allow a smooth engagement. If the planks are not aligned in the right position it could result in breaking the profile when using the tapping block and mallet.




Figure 4 - Use a tapping block and a hard mallet along both short ends to engage the planks. Place the tapping block over both short ends and tap it with the mallet until the ends are fully engaged. Please be careful not to damage the profile or edges while engaging the planks. Test each plank before proceeding to the next row to make sure they are fully engaged. Please refer to the installation instructions for detailed steps.

## DO'S AND DON'T FOR SHORT SIDE ENGAGEMENT

